

MAGNOLIA PATCH LIST - MAIN STAGE_SUMMER 2025

ID	MANUFACTURE	MODEL	MODE	UNI-ADDRESS	POSITION	FIXTURE INFO
101	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	3-001	TRUSS BACK	
102	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	3-035	TRUSS BACK	
103	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	3-069	TRUSS BACK	
104	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	3-103	TRUSS BACK	
105	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	3-137	TRUSS BACK	
106	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	3-171	TRUSS BACK	
107	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	3-205	TRUSS BACK	
108	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	3-239	TRUSS BACK	
201	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	3-273	TRUSS BACK	
202	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	3-295	TRUSS BACK	
203	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	3-317	TRUSS BACK	
204	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	3-339	TRUSS BACK	
205	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	3-361	TRUSS BACK	
206	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	3-383	TRUSS BACK	
207	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	3-405	TRUSS BACK	
208	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	3-427	TRUSS BACK	
501	SGM	X-5	4 ch, 8bit	3-449	TRUSS BACK	
502	SGM	X-5	4 ch, 8bit	3-453	TRUSS BACK	
109	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	2-001	TRUSS MID	
110	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	2-035	TRUSS MID	
111	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	2-069	TRUSS MID	
112	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	2-103	TRUSS MID	
113	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	2-137	TRUSS MID	
114	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	2-171	TRUSS MID	
115	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	2-205	TRUSS MID	
116	ROBE	ROBIN MEGAPOINTE	MODE 2, 34ch.	2-239	TRUSS MID	
209	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	2-273	TRUSS MID	
210	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	2-295	TRUSS MID	
211	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	2-317	TRUSS MID	
212	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	2-339	TRUSS MID	
213	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	2-361	TRUSS MID	
214	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	2-383	TRUSS MID	
215	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	2-405	TRUSS MID	
216	ROBE	ROBIN LEDBEAM 350	MODE 1, 22ch.	2-427	TRUSS MID	
503	SGM	X-5	4 ch, 8bit	2-449	TRUSS MID	
504	SGM	X-5	4 ch, 8bit	2-453	TRUSS MID	
301	BLINDER	2 CELL	DIMMER 1ch.	1-001	TRUSS BACK	
302	BLINDER	2 CELL	DIMMER 1ch.	1-002	TRUSS BACK	
303	BLINDER	2 CELL	DIMMER 1ch.	1-003	TRUSS BACK	
304	BLINDER	2 CELL	DIMMER 1ch.	1-004	TRUSS BACK	
305	BLINDER	2 CELL	DIMMER 1ch.	1-005	TRUSS MID	
306	BLINDER	2 CELL	DIMMER 1ch.	1-006	TRUSS MID	
307	BLINDER	2 CELL	DIMMER 1ch.	1-007	TRUSS MID	
308	BLINDER	2 CELL	DIMMER 1ch.	1-008	TRUSS MID	
309	BLINDER	2 CELL	DIMMER 1ch.	1-009	TRUSS FRONT	
310	BLINDER	2 CELL	DIMMER 1ch.	1-010	TRUSS FRONT	
311	BLINDER	2 CELL	DIMMER 1ch.	1-011	TRUSS FRONT	
312	BLINDER	2 CELL	DIMMER 1ch.	1-012	TRUSS FRONT	
313	PROFILE 575W	50°	DIMMER 1ch.	1-013	SIDE SR (Layher)	
314	PROFILE 575W	50°	DIMMER 1ch.	1-014	SIDE SL (Layher)	
401	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-033	TRUSS FRONT	Dedicated for banner
402	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-054	TRUSS FRONT	
403	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-075	TRUSS FRONT	
404	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-096	TRUSS FRONT	
405	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-117	TRUSS FRONT	
406	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-138	TRUSS FRONT	
407	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-159	TRUSS FRONT	
408	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-180	TRUSS FRONT	
409	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-201	TRUSS FRONT	
410	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-222	TRUSS FRONT	Dedicated for banner
411	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-243	SIDE SR (Layher)	
412	ROBE	ROBIN 600 LED WASH	MODE 2, 21ch.	1-264	SIDE SL (Layher)	
901	MARTIN JEM	COMPACT HAZER PRO	STANDARD, 3ch.	1-501	FLOOR SR	1 HAZER / 2 FAN / 3 CONTROL
902	MARTIN JEM	COMPACT HAZER PRO	STANDARD, 3ch.	1-504	FLOOR SL	1 HAZER / 2 FAN / 3 CONTROL
903	ANTARI	Z3000 (FOG)	DIMMER 1ch.	1-500	FLOOR CENTRE	